

Bay Series Center Drain

Installation for Concrete Slab



I. Frame out shower surround as required.

II. Connect drain outlet **A** to waste pipe **B**.

III. Pour concrete slurry to the height of the channel bottom **C**, pitch at a 1/4" per foot slope in four directions towards the shower base.

IV. Trowel mortar to required height.

V. Once floor mortar has cured, apply thin set and install tile and grout.

VI. Install the grate into the shower linear base.

Note:

- QM recommends this product to be installed by a licensed contractor.
- Lifting key assists with grate removal.
- Failure to achieve adequate floor slope will result in standing water problems or slow water flow.

