

Lagos Series Veil Linear Drain. Installation for concrete slab

Step 1. Determine where the drain will be positioned, frame out shower surround as required.

Step 2. Connect drain outlet **A** to waste pipe **B** using a no hub coupling. Use a mortar bed under the length of the base to support and level the drain channel.

Step 3. Pour concrete slurry to the height of the channel bottom **C**, pitch at a 1/4" per foot slope in direction towards the shower base.

Step 4. Install hot-mop or liquid membrane per manufacturer's instructions, fully covering concrete **C**.

Step 5. Trowel mortar to required height.

Step 6. Once floor mortar has cured, apply thin set and install tile and grout.

Step 7. For Tile-in spread a layer of mortar into the Tile-in frame, allowing for thinset and material to finish flush with metal frame.

Step 8. Install the grate into the shower linear base **I**.

Note:

- QM recommends this product to be installed by a licensed contractor.
- Failure to achieve adequate floor slope will result in standing water problems or slow water flow.
- Key used to remove Grate from Base.
- Hair Strainer basket fits inside the drain to collect hair and other debris preventing pipe clogs. Empty basket as needed to maintain optimal performance. The use of the basket is optional.

