

## Bay Series Ria Center Drain. Installation for concrete slab

**Step 1.** Frame out shower surround as required.

**Step 2.** Connect drain outlet **A** to waste pipe **B**.

**Step 3.** Pour concrete slurry to the height of the channel bottom **C**, pitch at a 1/4" per foot slope in four directions towards the shower base.

**Step 4.** Trowel mortar to required height.

**Step 5.** Once floor mortar has cured, apply thin set and install tile and grout.

**Step 6.** Install the grate into the shower linear base.

**Note:**

- QM recommends this product to be installed by a licensed contractor.
- Lifting key assists with grate removal.
- Failure to achieve adequate floor slope will result in standing water problems or slow water flow.

