

Lagos Series Veil Linear Drain. Standard installation for wood sub-floor

Step 1. Determine where the drain will be positioned, frame out shower surround as required.

Step 2. Connect drain flange body **A** to the drain pipe, leaving drain bolts in place. Block drain opening with rag to prevent floor mortar blocking pipe work.

Step 3. Trowel mortar onto subfloor **B**, pitch at a 1/4" per foot slope in direction towards the shower base.

Step 4. Install waterproof membrane **C**, reinforce around outlet and cut carefully to expose heads of drain bolts and outlet. Install clamping ring **D**.

Step 5. Test membrane for leaks.

Step 6. Screw threaded nipple into the drain flange, adjust to desired height **E**.


Step 7. Place the drain channel **F** into the threaded nipple. Use a mortar bed under the length of the base to support and level the drain channel.

Step 8. Trowel mortar to required height **G**.

Step 9. Once floor mortar has cured, apply thin set and install tile and grout **H**.

Step 10. For Tile-in spread a layer of mortar into the Tile-in frame, allowing for thinset and material to finish flush with metal frame.

Step 11. Install the grate into the shower linear base **I**.



Note:

- Waterproof membrane should be installed and tested per manufacturer's instructions and local building and plumbing codes.
- QM recommends this product to be installed by a licensed contractor.
- QM drain fits into most common 2" ABS, PVC or Cast Iron shower drain flange.
- Failure to achieve adequate floor slope will result in standing water problems or slow water flow.
- Key used to remove Grate from Base.
- Hair Strainer basket fits inside the drain to collect hair and other debris preventing pipe clogs. Empty basket as needed to maintain optimal performance. The use of the basket is optional.